

# COMMANDO RVS ACHTERREM VOETSTEUN / STAINLESS REARBRAKE FOOTRESTS

NUMMER / PARTNR.	DISCRIPTION/ BENAMING	BOUWJAAR / YEARS USED	EURO / PRICE INCL 19% BTW
<i>Lug, rear footrest</i>			
06-0487SS	Scharnier achtervoetsteun	1968-1977	€14,00
<i>Rear footpeg</i>			
06-0616SS	Voetsteun arm achter	1963-1977	€13,00
<i>Bolt, mounting rear footrest</i>			
06-0618SS	Bout voetsteunlug/dempersteun	1968-1977	€2,50
<i>Spring brakelever</i>			
06-0704SS	Veer achterrem hevel	1968-1974	€7,00
<i>Bolt, hinge rear footpeg</i>			
06-1798SS	Scharnierbout achtervoetsteunarm	1968-1977	€3,00
<i>Bolt kit, damper stays / alloy plates</i>			
EMW-11SS	Boutkit dempersteunen op alu. Platen	1968-1974	€20,00
<i>Bolt kit, footrests / alloy plates</i>			
EMW-12SS	Bout kit voetsteunarmen/alu. platen	1975-1977	€9,00
<i>Bolt kit, footrests / alloy plates</i>			
EMW-16SS	Bout kit voetsteunarmen alu. platen	1968-1974	€13,00
<i>Nut + washer, front footpeg</i>			
EMW-18SS	Moer + ring voetsteunpen voor	1968-1977	€2,00
<i>Spring, brake pedal</i>			
EMW-413SS	Veer rempendaal, rempendaal valt	1968-1974	€9,00
<i>Bolt kit, alloy plates / frame</i>			
EMW-8SS	Boutkit aluminiumplaten op frame	1968-1977	€10,00